




Programming manual
Supplement

efector190[®]

UK

Communication between
multicode reader O2I1xx
and Siemens Simatic S7



Contents

1	Preliminary note	3
1.1	Symbols used	3
2	General	3
3	Ethernet connection via TCP protocol	4
3.1	Principles	4
3.2	Set-up of the multicode reader	4
3.3	Set-up of the hardware configuration / NetPro Step7	7
3.4	Setting parameters on function block FB50	10
3.5	Description function block FB50	10
4	Serial connection via ASCII driver	12
4.1	Principles	12
4.2	Set-up of the multicode reader	12
4.3	Set-up in step 7	14
4.4	Setting parameters on function block FB49	17
4.5	Function block description FB49	17



Licences and trademarks

Microsoft®, Windows®, Windows XP® and Windows Vista® are registered trademarks of Microsoft Corporation. All trademarks and company names are subject to the copyright of the respective companies.

1 Preliminary note

These instructions serve for the set-up and parameter setting of the communication between the multicode reader O2I1xx from ifm electronic and a Simatic S7 controller from Siemens.

1.1 Symbols used

- ▶ Instruction
- > Reaction, result
- [...] Designation of pushbuttons, buttons or indications
- Cross-reference
-  Important note
Non-compliance can result in malfunctions or interference.
-  Information
Supplementary note

UK

2 General

Communication via Ethernet or serial communication is possible.

The following functions can be executed:

- Release trigger
(code read, fail string or match string are provided)
- Select configuration/group
(confirmation is given)
- Enquire configuration
(list of all configurations is provided)
- Enquire statistics
(number of readings is provided)

3 Ethernet connection via TCP protocol

3.1 Principles

The data of the TCP connection is transmitted as a data flow, i.e. there is no defined start or end character on the protocol level.

The returned data is received byte for byte and stored in the receive buffer.


For communication via Ethernet, all TCP protocol compatible Ethernet CPs can be used.

However, the different selection of the Siemens communication blocks when using controllers of the 300 or 400 series is to be taken into account.


The communication was tested with a CPU 414-2DP and a CP 443-1.

3.2 Set-up of the multicode reader

- ▶ Select Global device settings → Process interface → Selection of the process interface → TCP/IP.




- ▶ Select Global device settings → Network parameters → set IP address.




UK

- ▶ Select the trigger type "Serial" in the active configuration.



3.3 Set-up of the hardware configuration / NetPro Step7

- Set up and link the multicode reader as "Andere Stationen" in NetPro.



UK

- ▶ Create TCP connection with multicode reader.
- ▶ Note down the connection ID and CP address for the function block parameter setting.

The screenshot shows the 'Eigenschaften - TCP-Verbindung' dialog box in Siemens NetPro. The 'Allgemein' tab is active, displaying the following configuration:

- Lokaler Endpunkt:**
 - ID (Hex): 0001 A050
 - Name: TCP-Verbindung
 - Über CP: CP 443-1 - (R0/S3)
 - Aktiver Verbindungsaufbau
- Bausteinparameter:**
 - 1 - ID
 - W#16#0FAA - LADDR

Below the dialog, a table lists the connection details:

Lokale ID	Partner ID	Partner	Typ
0001 A050		Lesegerät	TCP-Verbindung

- Set the port number as in the parameter setting software.

The screenshot shows the Siemens NetPro software interface. A central dialog box titled "Eigenschaften - TCP-Verbindung" is open, displaying the "Adressen" (Addresses) tab. The dialog contains the following information:

Die Ports von 1025 bis 65535 stehen zur Verfügung.
(Weitere Ports siehe Hilfe)

	Lokal	Partner
IP (DEZ):	192.168.0.78	192.168.0.79
PORT (DEZ):	50003	50003

Below the dialog, a table lists the network objects:


Lokale ID	Partner ID	Partner	Typ
0001 A050		Lesegerät	TCP-Verbindung


The right-hand side of the NetPro window shows a tree view of network objects under "Auswahl der Netzobjekte", including PROFIBUS-DP, PROFIBUS-PA, PROFINET IO, SIMATIC TDC, and various SIMATIC stations (PG/PC, 300, 400, H-Station, HMI Station, OP, PC Station, S5). A status bar at the bottom indicates "Bereit" and "TCP/IP -> Broadcom NetXtreme 57x...".

UK

3.4 Setting parameters on function block FB50

- Indicate ID and LADDR as set up in Net-Pro.
(Are forwarded to the communication function blocks.)



 The parameter RECV_BUF must be declared as absolute, because with some controller types the width of access may not be transmitted correctly in case of symbolic declaration.

3.5 Description function block FB50

The function block establishes the telegrams to be sent to the multicode reader and creates a character string from the received data flow.

The "trigger" input sends a trigger command to the multicode reader with each positive edge. In addition the receive buffer is deleted.

The "change_group" input sends a change group command to the multicode reader with each positive edge. The selection is indicated at the "group_nr" and "conf_nr" inputs. In addition the receive buffer is deleted.

The "read_conf" and "read_stat" inputs send the corresponding status query to the multicode reader with each positive edge. In addition the receive buffer is deleted.

The received data is read byte-by-byte from the data flow and then stored consecutively in the receive buffer.

The length of the receive buffer is defined variably as ANY pointer and can be extended or reduced according to the respective requirements.

The character string received from the configuration software after the start and end characters have to be evaluated externally.



4 Serial connection via ASCII driver

4.1 Principles


The received data is received byte for byte and stored in the receive buffer.

All PtP CPs with ASCII protocol driver can be used for serial communication. In that case, however, the transmitting and receiving function blocks used in FB49 have to be adapted accordingly.


The communication was tested with a CPU 414-2DP, a CP 440 and an RS-485/RS-232 interface converter.

4.2 Set-up of the multicode reader

- ▶ Select Global device settings → Process interface → Selection of the process interface → "Serial".



- ▶ Select Global device settings → set transfer parameters (here 9600 8N1).
- ▶ Select the trigger type "Serial" in the active configuration.




UK

4.3 Set-up in step 7

- ▶ Set up an ASCII coupling for the corresponding CP and define the telegram length 1 byte.

All other settings depend on the CP used.

Below as an example the setting of a CP 440 with interface converter:




The screenshot shows the SIMATIC Manager HW Config interface for a SIMATIC 400 system. The main window displays a rack configuration for 'UR1' with the following components:

Steckplatz	Baugrupp...	B...
1	PS 405 4A	6ES
2	CPU 414-2 DP	6ES
X2	DP	
X1	MPI/DP	
3	CP 443-1	6GK
4	CP 440	6ES
5		
6		
7		
8		
9		

The 'Punkt-zu-Punkt-Kopplung parametrieren' dialog shows a connection between two CP 440 modules. The 'Protokoll' dialog is open, showing the following settings:


- Protokoll: ASCII
- Empfangspuffer auf CP:
 - CP-Empfangspuffer im Anlauf löschen
 - Überschreiben verhindern
 - gesamten Puffer ausnutzen
- Gepufferte Empfangstelegramme: 1

UK



4.4 Setting parameters on function block FB49

- ▶ Enter parameters for the CP address.
(Are forwarded to the communication function blocks.)



UK

The parameters SEND_DB_BUF, SEND_DBB_NO, RECV_DB_BUF und RECF_DBB_NO are the start addresses for an intermediate buffer needed for this coupling.



The parameter RECV_BUF must be declared as absolute, because with some controller types the width of access may not be transmitted correctly in case of symbolic declaration.

4.5 Function block description FB49

The function block establishes the telegrams to be sent to the multicode reader and creates a character string from the received data flow.

The "trigger" input sends a trigger command to the multicode reader with each positive edge. In addition the receive buffer is deleted.

The "change_group" input sends a change group command to the multicode reader with each positive edge. The selection is indicated at the inputs "group_nr" and "conf_nr". In addition the receive buffer is deleted.

The "read_conf" and "read_stat" inputs send the corresponding status query to the multicode reader with each positive edge. In addition the receive buffer is deleted.

The received data is read byte-by-byte from the CP and then stored consecutively in the receive buffer.

The length of the receive buffer is defined variably as ANY pointer and can be extended or reduced according to the respective requirements.

For the serial coupling there is an additional intermediate buffer for the telegram to be sent and the telegram to be received. Stored here in DB200, parameters can be set at the inputs SEND_DB_BUF, SEND_DBB_NO, RECV_DB_BUF and RECF_DBB_NO.

The character string received from the configuration software after the start and end characters have to be evaluated externally.