

## Sonderausstattung mit Flammenüberwachung

### Funktion

Ein Lichtfühler überwacht die Brennerflamme. Beim Erlöschen wird die Brennstoffzufuhr unterbrochen

### Kontroll-Lampe leuchtet auf

- Flamme erlischt während des Betriebes
- Schauglas stark verschmutzt, Lichtfühler wird nicht belichtet.
- Lichtfühler defekt oder nicht angeschlossen.

### Kontroll-Lampe blinkt

- Brennstofftank ist leer (Niveaufühler B6)

### Kein Brennerbetrieb

- Lichtfühler steckt nicht im Halter (Fremdlicht)

### Bei Störung

Geräteschalter auf Stellung 0

Nach Behebung Gerät wieder einschalten.

## Special equipment with flame control

### Function

A photocell observes the flame of the burner. After flame extinguishing the fuel feed will interrupt.

### When the fuel monitor signal lamp lights

- Flam has extinguished during operation
- Sight glass very dirty, no light reaches photocell
- Photocell is not electrically connected

### When the fuel monitor signal lamp flashes on and off

- Fuel tank is empty

### Burner operation is not possible

- Photocell is not secured in its holder (stray light)

### In the event of fault

Turn the on/off switch to position 0.

After correcting the fault, switch the machine on again.

### Sonderausstattung mit Flammenüberwachung

#### Funktion

Ein Lichtfühler überwacht die Brennerflamme.  
Beim Erlöschen wird die Brennstoffzufuhr  
unterbrochen

#### Kontroll-Lampe leuchtet auf

- Flamme erlischt während des Betriebes
- Schauglas stark verschmutzt, Lichtfühler wird nicht belichtet.
- Lichtfühler defekt oder nicht angeschlossen.

#### Kontroll-Lampe blinkt

- Brennstoftank ist leer (Niveaufühler B6)

#### Kein Brennerbetrieb

- Lichtfühler steckt nicht im Halter (Fremdlicht)

#### Bei Störung

Geräteschalter auf Stellung 0

Nach Behebung Gerät wieder einschalten.

### Special equipment with flame control

#### Function

A photocell observes the flame of the burner.  
After flame extinguishing the fuel feed will  
interrupt.

#### When the fuel monitor signal lamp lights

- Flam has extinguished during operation
- Sight glass very dirty, no light reaches photocell
- Photocell is not electrically connected

#### When the fuel monitor signal lamp flashes on and off

- Fuel tank is empty

#### Burner operation is not possible

- Photocell is not secured in its holder (stray light)

#### In the event of fault

Turn the on/off switch to position 0.

After correcting the fault, switch the machine on  
again.