Crankset, bottom bracket and chainline (MTB & Comfort)

In order to use SIS to its full extent, the required correct chainline, along with the crankset and bottom bracket required to obtain that, are given in the chart below.

| Series | FC | | | | BB | Chainline & Axle mark | | | |
|------------|--------------------------|--------|--------|-----------|-----------------------|---------------------------|--------|--------|-------|
| | Type of Crank | | | | | 47.5mm 50.0mm 52.5mm 47.5 | | | |
| | Model NO. | Spline | Square | Chaincase | Model NO. | 47.5mm | 50.0mm | 52.5mm | + tmm |
| XTR | FC-M960 | Х | | | included | | | • | |
| SAINT | FC-M800-1 | | | | | Chainline 50.0 mm | | | |
| | FC-M800-2 | Х | | | included | | | | |
| | FC-M800-3 | | | | | | | | |
| | FC-M805-1 | | | | | Chainline 57.5 mm | | | |
| | FC-M805-1 FC-M805-2 | Х | | | included | | | | |
| | FC-M805-3 | | | | | | | | |
| DEORE XT | FC-M760 | Х | | | included | Chainline 50.0 mm | | | |
| | FC-M761 | Х | | Х | included | | | | |
| DEORE LX | FC-M580 | Х | | | included | | | | |
| | FC-M581 | Х | | Х | included | | | | |
| HONE | FC-M600 | Х | | | included | | | | |
| DEORE | FC-M510-O | Х | | | BB-ES51(-E) | 113 | 118 | _ | _ |
| | FC-M510-KO | Х | | Х | BB-ES51-K | | | _ | 121 |
| | FC-M540 | Х | | | BB-ES51(-E) | 113 | 118 | _ | |
| | FC-M540-K | Х | | Х | BB-ES51-K | 121 | 126 | _ | 121 |
| | FC-M470 (44T) | Х | | Х | BB-ES51/30 (-K) | 121 | 126 | _ | 121 |
| | FC-M470 (48T) FC-M460 | Х | | Х | BB-ES51/30 (-K) | 121 | 126 | _ | 121 |
| | FC-M460 | | Х | Х | BB-UN25 (-K) | 117.5 | _ | _ | 117.5 |
| | FC-M440 (48T) | | Х | Х | BB-UN25 (-K) | 117.5 | _ | _ | 117.5 |
| | FC-M440-O | Х | | | BB-ES51/30(-E) | 113 | 118 | _ | _ |
| | FC-M440 | | Х | | BB-UN25(-E) | MM110 | LL113 | _ | _ |
| NEXAVE | FC-C810 | | Х | X*** | BB-UN25 | _ | 130 | _ | _ |
| | FC-C505 | | Х | X*** | | _ | 130 | _ | _ |
| | FC-C600 | | Х | Х | BB-UN25-K | _ | _ | 117.5 | _ |
| | FC-C503 | | | Х | | 123 | 123 | _ | 123 |
| | FC-C530 | | Х | Х | BB-TS30/UN25-K | | | | |
| | FC-C510 ** | | Х | X*** | BB-UN25 | _ | 123 | 123 | _ |
| | FC-T410 | | Х | X | BB-UN25-K | _ | _ | _ | 117.5 |
| | FC-T411 | | Х | Х | | _ | _ | _ | |
| | FC-T300-S | | X | Х | BB-UN25(-E) | YL117 | ZL122 | _ | _ |
| | FC-T303 | | Х | Х | | ILII/ | LLIZZ | _ | _ |
| ALIVIO | FC-MC20 | | X | | | | | _ | _ |
| | FC-MC19 | | Х | | BB-UN25(-E) / (-K) | MM110 | LL113 | _ | _ |
| ACERA | FC-M340 | | Х | Х | | IVIIVI I IU | LLIIS | _ | MM110 |
| Non-series | FC-MC08 | | Х | | _ / (-N) | | | _ | _ |
| TOURNEY | FC-TY40 | | Х | | | YL117 | ZL122 | _ | _ |
| C-series | FC-C051/050 | | Х | Х | BB-UN25 | D-NL | _ | _ | _ |
| TOURNEY | FC-TX70/TX71 | | Х | Х | DD-UNZU | (122.5) | _ | _ | _ |

without chaincase stay

X : Yes

right hand BB adapter.

^{**} BB-UN25 bottom brackets parts for FC-C510 includes 1.8mm and 0.7mm thickness spacers.
In case of without chaincase, use both spacers between hanger and right hand BB adapter.
In case of with chaincase, use 0.7 mm thickness spacer only. Put chaincase stay with 0.7 mm thickness spacer between hanger and

^{***} Chaincase stay thickness should be 1.5 mm to 2.1 mm.