
FIRST BERN CYCLOTRON SYMPOSIUM / June 6-7, 2011 ZAG Zyklotron AG



ZAG Zyklotron AG







Business of ZAG Zyklotron AG

Development, production, marketing of innovative radioactive products of highest quality for


ENGINEERING	MEDICINE
- THIN LAYER ACTIVATION	- 123 I
- WEAR MEASUREMENT INSTRUMENTS	- 18 FDG
	- KIPROS

Our staff: 26 people, among them 8 graduates



ZAG Zyklotron AG operates two cycotrons


KAZ 15 - 40 MeV protons, up to 200 μA MIZ 18 MeV protons, up to 250 μ A 9 MeV deuterons, up to 60 μ A







Working Principle of RTM RADIONUCLIDE-TECHNIQUE in MECHANICAL ENGINEERING





Progress Steps of RTM in Karlsruhe

1958 1964 2008

- Neutron activation in a nuclear reactor
- •Complete part is radioactive
- Some metals
- High effort for radiation protection
- •Accuracy: μg, μm


- •TLA Thin Layer
 Activation at cyclotron
- Activation depth of20 μm to 2 mm
- Metals, alloys, some ceramic materials
- Low effort for radiation protection
- •Accuracy: sub-μg, -μm

- UTLA Ultra Thin Layer Activation
- Activation depth in the range of 5 μm
- •Most of synthetic and ceramic materials (DLC, PTFE, PEEK, Al₂O₃, etc.)
- Very low effort for radiation protection
- Accuracy: ng, nm




<u>RTM</u> - <u>RADIONUCLIDE-TECHNIQUE</u> in <u>MECHANICAL ENGINEERING</u> Wear- and Corrosion-Diagnostics of Running Machines and Processing Engineering

RTM - Activation Service




Set-up of a piston ring of a marine diesel engine in front of the beam head for irradiation









<u>RTM</u> - <u>RADIONUCLIDE-TECHNIQUE in <u>M</u>ECHANICAL ENGINEERING Wear- and Corrosion-Diagnostics of Running Machines and Processing Engineering</u>










FIRST BERN CYCLOTRON SYMPOSIUM / June 6-7, 2011 ZAG Zyklotron AG



Heavy Cast Iron Crankcase in Activation Position





Set of Rail-Wheels of a High-Speed Train for Thin Layer Activation

